
atos

Digital proportional directional valves

piloted, without transducer, with positive spool overlap





2 OFF-BOARD ELECTRONIC DRIVERS - only for A


Drivers model	E-MI-A	E-MI-AC-01F		E-MI-AS-IR		AS-PS	E-BM-AES	
Type Analog Digital								
Voltage supply (VDC)	12	24	12	24	12	24	24	
Valve coil option	/6	std	/6	std	/6	std	std	
Format		plug-in to	solenoid	DIN-rail panel				
Tech table	G	010	G020 G030 GS05		GS050			

3 GENERAL NOTES

Atos digital proportionals valves are CE marked according to the applicable directives (e.g. Immunity and Emission EMC Directive). Installation, wirings and start-up procedures must be performed according to the general prescriptions shown in tech table **FS900** and in the user manuals included in the E-SW-* programming software.

4 VALVE SETTINGS AND PROGRAMMING TOOLS

USB or Bluetooth connection



Valve's functional parameters and configurations, can be easily set and optimized using Atos E-SW programming software connected via USB port to the digital driver (see table **FS900**). For fieldbus versions, the software permits valve's parameterization through USB port also if the driver is connected to the central machine unit via fieldbus.

The software is available in different versions according to the driver's options (see table **GS500**): **E-SW-BASIC** support: NP (USB) PS (Serial) IR (Infrared)

		()	()	
E-SW-FIELDBUS	support:	BC (CANopen)	BP (PROFIBUS DP)	EH (EtherCAT)
		EW (POWERLINK)	EI (EtherNet/IP)	EP (PROFINET)
E-SW-*/PQ	support:	valves with SP. SF.	SL alternated control (e.a. E-SW-BASIC/P

E-SW-*/PQ support: valves with SP, SF, SL alternated control (e.g. E-SW-BASIC/PQ)

WARNING: drivers USB port is not isolated! For E-C-SB-USB/M12 cable, the use of isolator adapter is highly recommended for PC protection

WARNING: see tech table GS500 for the list of countries where the Bluetooth adapter has been approved

5 FIELDBUS - only for AES, see tech. table GS510

Fieldbus allows valve direct communication with machine control unit for digital reference, valve diagnostics and settings. These execution allow to operate the valves through fieldbus or analog signals available on the main connector.

6 GENERAL CHARACTERISTICS

Assembly position	Any position				
Subplate surface finishing to ISO 4401	Acceptable roughness index: Ra ≤ 0,8, recommended Ra 0,4 – Flatness ratio 0,01/100				
MTTFd valves according to EN ISO 13849	75 years, see technical table P007				
Ambient temperature range	A: Standard = -20°C ÷ +70°C /PE option = -20°C ÷ +70°C /BT option = -40°C ÷ +60°C AEB, AES: Standard = -20°C ÷ +60°C /PE option = -20°C ÷ +60°C /BT option = -40°C ÷ +60°C				
Storage temperature range	A:Standard = $-20^{\circ}C \div +80^{\circ}C$ /PE option = $-20^{\circ}C \div +80^{\circ}C$ /BT option = $-40^{\circ}C \div +70^{\circ}C$ AEB, AES:Standard = $-20^{\circ}C \div +70^{\circ}C$ /PE option = $-20^{\circ}C \div +70^{\circ}C$ /BT option = $-40^{\circ}C \div +70^{\circ}C$				
Surface protection	Zinc coating with black passivation, galvanic treatment (driver housing for AEB and AES)				
Corrosion resistance	Salt spray test (EN ISO 9227) > 200 h				
	CE according to EMC directive 2014/30/EU (Immunity: EN 61000-6-2; Emission: EN 61000-6-3)				
Compliance	RoHS Directive 2011/65/EU as last update by 2015/65/EU				
	REACH Regulation (EC) n°1907/2006				

7 HYDRAULIC CHARACTERISTICS - based on mineral oil ISO VG 46 at 50 °C

Valve model		DPZO-*-1	DPZC)-*-2	DPZO-*-4	DPZO-*-6
Pressure limits	[bar]			oorts P , A , B , X = 350 10 with internal drain		
Spool type L5, S5, D5 L3, S3, D3				L5, S5, D5		
Nominal flow Δp	P-T [l/min]					
(1)	$\Delta p=10 \text{ bar}$	100	160	250	480	640
_	Δp = 30 bar	160	270	430	830	1100
Max pern	nissible flow	180	400	550	900	1500
Piloting pressure [bar]		min = 25; max = 350 (option /G advisable for pilot pressure > 150 bar)				
Piloting volume	[cm ³]	1,4	3,	7	9,0	21,6
Piloting flow (2)	[l/min]	1,7	3,	7	6,8	14,4
Leakage (3)	[l/min]	0,15 / 0,5	0,2 /	0,6	0,3 / 1,0	1,0 / 3,0
Response time	(4) [ms]	≤ 80	≤ 1	00	≤ 120	≤ 180
Hysteresis	≤ 5 [% of max regulation]			•		
Repeatibility			±	1 [% of max regulation	on]	

Note: above performance data refer to valves coupled with Atos electronic drivers, see section (2) (1) For different Δp , the max flow is in accordance to the diagrams in section 9.2 (2) With step reference input signal 0 ÷100 %

(3) At p = 100/350 bar (4) 0-100% step signal



UAB "Domingos prekyba" www.dominga.lt/eshop email: info@dominga.lt

8 ELECTRICAL CHARACTERISTICS


Power supplies	Nominal Rectified and filtered	: +24 VDC : VRMS = 20 ÷ 32 VMAX	(ripple max 10 % VPP)		
Max power consumption	A = 30 W	AEB , AES = 50 W			
Coil voltage code	standard		option /6	option /18	
Max. solenoid current	2,2 A		2,75 A	1 A	
Coil resistance R at 20°C	3 ÷ 3,3 Ω		2 ÷ 2,2 Ω	13 ÷ 13,4 Ω	
Analog input signals		Voltage: range ± 10 VDc (24 VMAX tollerant)Input impedance: Ri > 50 k Ω Current: range ± 20 mAInput impedance: Ri = 500 Ω			
Monitor output	Output range: vo	tput range: voltage ±5 VDC @ max 5 mA			
Enable input	Range: 0 ÷ 9 VDC (OFF	state), 15 ÷ 24 VDC (ON	state), 9 ÷ 15 VDC (not ac	cepted); Input impedance: Ri > 87 k Ω	
Fault output	Output range : $0 \div 24$ VDC (ON state \cong VL+ [logic power supply] ; OFF state \cong 0 V) @ max 50 mA; external negative voltage not allowed (e.g. due to inductive loads)				
Pressure transducer power supply (only for /W option)	+24Vbc @ max 100 mA (E-ATR-8 see tech table GS465)				
Alarms			reak with current referend vel, pressure transducer	ce signal, over/under temperature, failure (/W option)	
Insulation class		0	atures of the solenoid coi 982 must be taken into a	·	
Protection degree to DIN EN60529	A = IP65; AEB, AES =	IP66 / IP67 with mating	g connectors		
Duty factor	Continuous rating (ED=	=100%)			
Tropicalization	Tropical coating on ele	ectronics PCB			
Additional characteristics		of solenoid's current s erse polarity of power s	11 57	P.I.D. with rapid solenoid switching;	
Communication interface	USB Atos ASCII coding	CANopen EN50325-4 + DS408	PROFIBUS DP EN50170-2/IEC61158	EtherCAT EC 61158	
Communication physical layer	not insulated USB 2.0 + USB OTG	optical insulated CAN ISO11898	optical insulated RS485	Fast Ethernet, insulated 100 Base TX	
Recommended wiring cable	LiYCY shielded cables	, see section 17			


Note: a maximum time of 500 ms (depending on communication type) have be considered between the driver energizing with the 24 Vbc power supply and when the valve is ready to operate. During this time the current to the valve coils is switched to zero.

9 SEALS AND HYDRAULIC FLUIDS - for other fluids not included in below table, consult our technical office

Seals, recommended fluid	temperature	NBR seals (standard) = $-20^{\circ}C \div +60^{\circ}C$ (+80°C for A), with HFC hydraulic fluids = $-20^{\circ}C \div +50^{\circ}C$ FKM seals (/PE option) = $-20^{\circ}C \div +80^{\circ}C$ HNBR seals (/BT option) = $-40^{\circ}C \div +60^{\circ}C$, with HFC hydraulic fluids = $-40^{\circ}C \div +50^{\circ}C$				
Recommended viscosity		20 ÷ 100 mm²/s - max allowed r	20 ÷ 100 mm ² /s - max allowed range 15 ÷ 380 mm ² /s			
Max fluid	normal operation	ISO4406 class 18/16/13 NAS1638 class 7		see also filter section at		
contamination level longer life		ISO4406 class 16/14/11 NAS1	www.atos.com or KTF catalog			
Hydraulic fluid		Suitable seals type	Classification	Ref. Standard		
Mineral oils		NBR, FKM, HNBR	HL, HLP, HLPD, HVLP, HVLPD	DIN 51524		
Flame resistant without water		FKM	HFDU, HFDR	ISO 12922		
Flame resistant with water		NBR, HNBR	HFC	150 12922		







10 DIAGRAMS (based on mineral oil ISO VG 46 at 50 °C)

Note: Hydraulic configuration vs. reference signal for configuration 71 and 73 (standard and option /B)

Reference signal $\begin{array}{c} 0 \ \div +10 \ V \\ 12 \ \div \ 20 \ mA \end{array} \Big\} P \rightarrow A \, / \, B \rightarrow T$

Reference signal $\begin{array}{c} 0 \div -10 \text{ V} \\ 12 \div 4 \text{ mA} \end{array} \} P \rightarrow B / A \rightarrow T$



10.2 Flow /∆p diagram

stated at 100% of spool stroke

DPZO-1:

1 = spools L5, S5, D5


DPZO-2:

2 = spools L3, S3, D3 $\mathbf{3} = \text{spools L5}, \text{S5}, \text{D5}$

DPZO-4: 4 = spools L5, S5, D5

DPZO-6:


5 = spools L5, S5, D5



70100 Valve pressure drop ∆p [bar]

200 300


30





Valve pressure drop ∆p [bar]

10.3 Response time (measured at pilot pressure = 100 bar)

The response times in below diagrams are measured at different steps of the reference input signal. They have to be considered as average values. For the valves with digital electronics the dynamics performances can be optimized by setting the internal software parameters.







10.4 Operation as throttle valve

Single solenoid valves (*51) can be used as simple throttle valves: Pmax = 250 barFor this application, the use of valve -TEB or -TES (see tab. FS172) is advisable (consult our technical office)

ſ	А в					
		DPZO-*-	151-L5	251-L5	451-L5	651-L5
		Max flow [I/min] $\Delta p = 15 \text{ bar}$	320	860	1600	2200



UAB "Domingos prekyba" www.dominga.lt/eshop email: info@dominga.lt

11 HYDRAULIC OPTIONS

- **B** = DPZO-*-*5 = solenoid and on-board digital driver at side B of the main stage (side A of pilot valve). DPZO-*-*7 = on-board digital driver at side of port B of the main stage (side A of pilot valve).
- **D** = Internal drain. Pilot and drain configuration can be modified as shown in section 18 The valve's standard configuration provides internal pilot and external drain.
- \mathbf{E} = External pilot (through port X). Pilot and drain configuration can be modified as shown in section 18 The valve's standard configuration provides internal pilot and external drain.
- G = Standard for size 10. Pressure reducing valve installed between pilot valve and main body with fixed setting: DPZO-1 and DPZO-2 = 40 bar DPZO-4 and DPZO-6 = 100 bar It is advisable for valves with internal pilot in case of system pressure higher than 150 bar.

12 ELECTRONICS OPTIONS - only for AEB and AES

I = This option provides 4 ÷ 20 mA current reference and monitor signals, instead of the standard ±10 VDC

Input signal can be reconfigured via software selecting between voltage and current, within a maximum range of ±10 VDC or ±20 mA.

It is normally used in case of long distance between the machine control unit and the valve or where the reference signal can be affected by electrical noise; the valve functioning is disabled in case of reference signal cable breakage.

Q = This option permits to inhibit the valve function without removing the power supply to the driver. Upon disable command the current to the solenoid is zeroed and the valve's spool moves to rest position

The option /Q is suggested for all cases where the valve has to be frequently inhibited during the machine cycle - see 15.5 for signal specifications.

Z = This option provides, on the 12 pin main connector, the following additional features: Fault output signal - see 15.6 Enable input signal - see above option /Q

Power supply for driver's logics and communication - see 15.2

C = Only in combination with option /W

This option is available to connect pressure transducers with 4 - 20 mA current output signal, instead of the standard ±10 VDC.

Input signal can be reconfigured via software selecting between voltage and current, within a maximum range of ±10 VDC or ±20 mA.

W = Only for valves coupled with pressure compensator, see tech table D150. It provides the hydraulic power limitation function. The driver receives the flow reference signal by the analog input INPUT+ and a pressure transducer, installed in the hydraulic system, has to be connected to the driver's analog input TR. When the actual requested hydraulic power **p**xQ (TR x INPUT+) reaches the max power limit (p1xQ1), internally set by software, the driver automatically reduces the flow regulation of the valve. The higher is the pressure feedback the lower is the valve's regulated flow:

PowerLimit [sw setting] Flow regulation = Min (; Flow Reference [INPUT+]) Transducer Pressure [TR]

13 POSSIBLE COMBINED OPTIONS

Hydraulic options: all combination possible Electronics options: /IQ, /IZ, /IW, /CW, /CWI

14 COIL VOLTAGE OPTIONS - only for A

6 = Optional coil to be used with Atos drivers with power supply 12 VDC.

18 = Optional coil to be used with electronic drivers not supplied by Atos, with power supply 24 VDc and with max current limited to 1A.

15 POWER SUPPLY AND SIGNALS SPECIFICATIONS - only for AEB and AES

Generic electrical output signals of the valve (e.g. fault or monitor signals) must not be directly used to activate safety functions, like to switch-ON/OFF the machine's safety components, as prescribed by the European standards (Safety requirements of fluid technology systems and componentshydraulics, ISO 4413)

15.1 Power supply (V+ and V0)

The power supply must be appropriately stabilized or rectified and filtered: apply at least a 10000 µF/40 V capacitance to single phase rectifiers or a 4700 μ F/40 V capacitance to three phase rectifiers. In case of separate power supply see 15.2.

A safety fuse is required in series to each power supply: 2,5 A time lag fuse.

15.2 Power supply for driver's logic and communication (VL+ and VL0) - only for /Z and /W options

The power supply for driver's logic and communication must be appropriately stabilized or rectified and filtered: apply at least a 10000 µF/40 V The separate power supply for driver's logic on pin 9 and 10, allow to remove solenoid power supply from pin 1 and 2 maintaining active the diagnostics, USB and fieldbus communications.

A safety fuse is required in series to each driver's logic and communication power supply: 500 mA fast fuse.

15.3 Reference input signal (INPUT+)

The driver controls in closed loop the current to the valve proportionally to the external reference input signal.

Reference input signal is factory preset according to selected valve code, defaults are ±10 Vpc for standard and 4 ÷ 20 mA for /I option. Input signal can be reconfigured via software selecting between voltage and current, within a maximum range of ±10 Vpc or ± 20 mA. Drivers with fieldbus interface (BC, BP, EH) can be software set to receive reference signal directly from the machine control unit (fieldbus reference). Analog reference input signal can be used as on-off commands with input range 0 ÷ 24Vbc.




UAB "Domingos prekyba" www.dominga.lt/eshop email: info@dominga.lt

INDUSTRY SERVICE Savanorių pr. 187- 4 korp., LT-02300 Vilnius, Lietuva, tel.: +370 5 2322231, faks. + 370 5 2648229

Functional Scheme


Example of configuration 7* 3 positions, spring centered



1) Pilot valve

- (2) Main stage
- (3) Pressure reducing valve
- ④ Plug to be added for external pilot trough port X
- (5) Plug to be removed for internal drain through port T

Hydraulic Power Limitation



15.4 Monitor output signals (MONITOR and MONITOR2)

The driver generates an analog output signal (MONITOR) proportional to the actual coil current of the valve; the monitor output signal can be software set to show other signals available in the driver (e.g. analog reference, fieldbus reference). Monitor output signal is factory preset according to selected valve code, default settings is $\pm 5 \text{ Vpc}$ (1V = 1A). Output signal can be reconfigured via software, within a maximum range of $\pm 5 \text{ Vpc}$.

The driver generates a second analog output signal (MONITOR2) proportional to the actual system pressure. The output maximum range is ±5 Vpc; default setting is 0 ÷ 5 Vpc.

15.5 Enable input signal (ENABLE) - not for standard

To enable the driver, supply a 24 Voc on pin 3 (pin C): Enable input signal allows to enable/disable the current supply to the solenoid, without removing the electrical power supply to the driver; it is used to active the communication and the other driver functions when the valve must be disabled for safety reasons. This condition **does not comply** with norms IEC 61508 and ISO 13849. Enable input signal can be used as generic digital input by software selection.

15.6 Fault output signal (FAULT) - only for /Z and /W options

Fault output signal indicates fault conditions of the driver (solenoid short circuits/not connected, reference signal broken for 4 ÷ 20 mA input, etc.). Fault presence corresponds to 0 Vpc, normal working corresponds to 24 Vpc. Fault status is not affected by the Enable input signal.

15.7 Remote pressure transducer input signal (TR+) - only for /W option

Analog pressure transducers can be directly connected to the driver (see 16.4). Analog input signal is factory preset according to selected driver code, defaults are $0 \div 10$ Vpc for standard and $4 \div 20$ mA for /C option. Input signal can be reconfigured via software selecting between voltage and current, within a maximum range of ±10 Vpc or ± 20 mA. Note: transducer feedback can be read as a digital information through fieldbus communication - software selectable.

16 ELECTRONIC CONNECTIONS

16.1 Main connector signals - 7 pin (A) Standard and /Q option - for AEB and AES

PIN	Standard /Q TECHNICAL SPECIFICATIONS		NOTES	
А	A V+		Power supply 24 Vbc	Input - power supply
В	в V0		Power supply 0 Vbc	Gnd - power supply
С	AGND		Analog ground	Gnd - analog signal
C	ENABLE		Enable (24 Vbc) or disable (0 Vbc) the driver, referred to V0	Input - on/off signal
D INPUT+			Reference input signal: ± 10 Vpc / ± 20 mA maximum range Defaults are ± 10 Vpc for standard and $4 \div 20$ mA for /l option	Input - analog signal Software selectable
E	E INPUT-		Negative reference input signal for INPUT+	Input - analog signal
F MONITOR referred to: AGND V0			Monitor output signal: ± 5 Vpc maximum range Default is ± 5 Vpc (1V = 1A)	Output - analog signal Software selectable
G	G EARTH		Internally connected to driver housing	

16.2 Main connector signals - 12 pin (A2) /Z and /W options - for AEB and AES

PIN	/Z	/W	TECHNICAL SPECIFICATIONS	NOTES
1	V+		Power supply 24 Vbc	Input - power supply
2	V0		Power supply 0 Vbc	Gnd - power supply
3	ENABLE		Enable (24 VDc) or disable (0 VDc) the driver, referred to VL0	Input - on/off signal
4	4 INPUT+		Reference input signal: ± 10 Vbc / ± 20 mA maximum range Defaults are ± 10 Vbc for standard and $4 \div 20$ mA for /I option	Input - analog signal Software selectable
5	5 INPUT-		Negative reference input signal for INPUT+	Input - analog signal
6	6 MONITOR		Monitor output signal: ± 5 Vbc maximum range, referred to VL0 Default is ± 5 Vbc (1V = 1A)	Output - analog signal Software selectable
7	NC		Do not connect	
8	NC		Do not connect	
0		MONITOR2	2nd monitor output signal: ±5 Vpc maximum range, referred to VL0. Default is 0 ÷ 5 Vpc	Output - analog signal
9	VL+		Power supply 24 Vbc for driver's logic and communication	Input - power supply
10	0 VLO		Power supply 0 Vpc for driver's logic and communication	Gnd - power supply
11	11 FAULT		Fault (0 Vbc) or normal working (24 Vbc), referred to VL0	Output - on/off signal
PE	EARTH		Internally connected to driver housing	

Note: do not disconnect VL0 before VL+ when the driver is connected to PC USB port

16.3 Communication connectors - for AEB (B) and AES (B) - (C)

(B) USB connector - M12 - 5 pin always present

U	oob connector with opin always present		
PIN	SIGNAL	TECHNICAL SPECIFICATION (1)	
1	+5V_USB	Power supply	
2	ID	Identification	
3	GND_USB	Signal zero data line	
4	D-	Data line -	
5	D+	Data line +	

C2	(c2) BP fieldbus execution, connector - M12 - 5 pin (2)			
PIN	SIGNAL	SIGNAL TECHNICAL SPECIFICATION (1)		
1	+5V	Termination supply signal		
2	LINE-A	Bus line (high)		
3	DGND	Data line and termination signal zero		
4	LINE-B	Bus line (low)		
5	SHIELD			

(1) Shield connection on connector's housing is recommended

(C1)	BC fieldbus execution, connector - M12 - 5 pin (2)			
PIN	SIGNAL	SIGNAL TECHNICAL SPECIFICATION (1)		
1	CAN_SHLD	Shield		
2	NC	do not connect		
3	CAN_GND	Signal zero data line		
4	CAN_H	Bus line (high)		
5	CAN_L	Bus line (low)		

C3 (C3 C4 EH fieldbus execution, connector - M12 - 4 pin (2)			
PIN	PIN SIGNAL TECHNICAL SPECIFICATION (1)			
1	TX+	Transmitter		
2	RX+	Receiver		
3	тх-	Transmitter		
4	RX-	Receiver		
Housing	SHIELD			

(2) Only for AES execution




UAB "Domingos prekyba" www.dominga.lt/eshop email: info@dominga.lt

16.4 Remote pressure transducer connector - M12 - 5 pin - only for /W option - for AEB and AES (D)

PIN	SIGNAL	TECHNICAL SPECIFICATION	Voltage	Current
1	VF +24V	Power supply +24Vbc	Connect	Connect
2	TR	Signal transducer maximum range ± 10 Vpc / ± 20 mA, software selectable Defaults are 0 \div 10 Vpc for standard and 4 \div 20 mA for /C option	Connect	Connect
3	AGND	Common GND for transducer power and signals	Connect	/
4	NC	Not Connect	/	/
5	NC	Not Connect	/	/

Remote pressure transducer connection - example




Note: connectors front view

16.5 Solenoid connection - only for A

PIN	SIGNAL	TECHNICAL SPECIFICATION	Connector code 666
1	COIL	Power supply	
2	COIL	Power supply	
3	GND	Ground	

16.6 AEB connections layout




(1) Use of metallic connectors is strongly recommended in order to fulfill EMC requirements (2) Pin layout always referred to driver's view



UAB "Domingos prekyba" www.dominga.lt/eshop email: info@dominga.lt

16.7 AES connections layout



(1) Use of metallic connectors is strongly recommended in order to fulfill EMC requirements

(2) Pin layout always referred to driver's view



UAB "Domingos prekyba" www.dominga.lt/eshop email: info@dominga.lt

17 CONNECTORS CHARACTERISTICS - to be ordered separately

17.1 Main connectors - 7 pin - for AEB and AES

CONNECTOR TYPE	POWER SUPPLY	POWER SUPPLY
CODE	(A1) ZM-7P	(A3) ZH-7P
Туре	7pin female straight circular	7pin female straight circular
Standard	According to MIL-C-5015	According to MIL-C-5015
Material	Metallic	Plastic reinforced with fiber glass
Cable gland	PG11	PG11
Recommended cable	LiYCY 7 x 0,75 mm ² max 20 m (logic and power supply) or LiYCY 7 x 1 mm ² max 40 m (logic and power supply)	LiYCY 7 x 0,75 mm ² max 20 m (logic and power supply) or LiYCY 7 x 1 mm ² max 40 m (logic and power supply)
Conductor size	up to 1 mm ² - available for 7 wires	up to 1 mm ² - available for 7 wires
Connection type	to solder	to solder
Protection (EN 60529)	IP 67	IP 67

17.2 Main connectors - 12 pin - for AEB and AES

CONNECTOR TYPE	POWER SUPPLY	POWER SUPPLY
CODE	(A2) ZM-12P	A4 ZH-12P
Туре	12pin female straight circular	12pin female straight circular
Standard	DIN 43651	DIN 43651
Material	Metallic	Plastic reinforced with fiber glass
Cable gland	PG13,5	PG16
Recommended cable	LiYCY 12 x 0,75 mm ² max 20 m (logic and power supply)	LiYCY 10 x 0,14mm ² max 40 m (logic) LiYY 3 x 1mm ² max 40 m (power supply)
Conductor size	0,5 mm ² to 1,5 mm ² - available for 12 wires	0,14 mm² to 0,5 mm² - available for 9 wires 0,5 mm² to 1,5 mm² - available for 3 wires
Connection type	to crimp	to crimp
Protection (EN 60529)	IP 67	IP 67

17.3 Fieldbus communication connectors - only for AES

CONNECTOR TYPE	BC CAN	lopen (1)	BP PROFI	BUS DP (1)	E	EH EtherCAT (2)
CODE	C1 ZM-5PF	C2 ZM-5PM	C1 ZM-5PF/BP	C2 ZM-5PM/BP	C1 C2	ZM-4PM/E
Туре	5 pin female straight circular	5 pin male straight circular	5 pin female straight circular	5 pin male straight circular		4 pin male straight circular
Standard	M12 coding A –	IEC 61076-2-101	M12 coding B –	IEC 61076-2-101	M12 co	ding D – IEC 61076-2-101
Material	Metallic		Me	tallic		Metallic
Cable gland	Pressure nut - cab	le diameter 6÷8 mm	Pressure nut - cab	le diameter 6÷8 mm	Pressure n	ut - cable diameter 4÷8 mm
Cable	CANbus Stand	dard (DR 303-1)	PROFIBUS	DP Standard	Ethe	ernet standard CAT-5
Connection type	screw	terminal	screw	terminal		terminal block
Protection (EN 60529)	IF	267	IF	° 67		IP 67

(1) E-TRM-** terminators can be ordered separately - see tech table GS500

(2) Internally terminated


17.4 Pressure transducer connectors - only for /W option

CONNECTOR TYPE	TRANSDUCER			
CODE	D1 ZH-5PM/1.5	D1 ZH-5PM/5		
Туре	5 pin male straight circular			
Standard	M12 coding A – IEC 61076-2-101			
Material	Plastic			
Cable gland	Connector moulded on cables			
Cable giand	1,5 m lenght	5 m lenght		
Cable	5 x 0,25 mm ²			
Connection type	molded cable			
Protection (EN 60529)	IP 67			



18 PLUGS LOCATION FOR PILOT/DRAIN CHANNELS

Depending on the position of internal plugs, different pilot/drain configurations can be obtained as shown below. To modify the pilot/drain configuration, proper plugs must only be interchanged. The plugs have to be sealed using loctite 270. Standard valves configuration provides internal pilot and external drain



19 FASTENING BOLTS AND SEALS

Туре	Size	Fastening bolts	Seals
DPZO	1 10	4 socket head screws M6x40 class 12.9 Tightening torque = 15 Nm	5 OR 2050; Diameter of ports A, B, P, T: Ø 11 mm (max)
	1 = 10		2 OR 108 Diameter of ports X, Y: $\emptyset = 5 \text{ mm}(\text{max})$
	2 = 16	4 socket head screws M10x50 class 12.9 Tightening torque = 70 Nm	4 OR 130; Diameter of ports A, B, P, T: Ø 20 mm (max)
		2 socket head screws M6x45 class 12.9 Tightening torque = 15 Nm	2 OR 2043 Diameter of ports X, Y: $\emptyset = 7 \text{ mm}(\text{max})$
	4 = 25	6 socket head screws M12x60 class 12.9 Tightening torque = 125 Nm	4 OR 4112; Diameter of ports A, B, P, T: Ø 24 mm (max)
			2 OR 3056 Diameter of ports X, Y: $\emptyset = 7 \text{ mm} (\text{max})$
	6 - 22	6 socket head screws M20x90 class 12.9 Tightening torque = 600 Nm	4 OR 144; Diameter of ports A, B, P, T: Ø 34 mm (max)
	6 = 32		2 OR 3056 Diameter of ports X, Y: Ø = 7 mm (max)



UAB "Domingos prekyba" www.dominga.lt/eshop email: info@dominga.lt

unting surface: 4401-05-05-0-05 (see table P005)	Mass [kg] A AEB, AES AES-EH DPZO-*-15 7,7 8,1 8,2
	DPZO-*-17 8,6 9 9,1
	DP2O-^-17 8,6 9 9,1 Option /G +0,9
	3 DPZO-AES-BC-1 DPZO-AES-BP-1
	option/G
Dotted line = double solenoid version	
= Air bleeding 3 = Space to remove the connectors	




21 INSTALLATION DIMENSIONS FOR DPZO-2 [mm]


ISO 4401: 2005


Mounting surface: 4401-07-07-0-05 (see table P005)


	Mass [kg]		
	Α	AEB, AES	AES-EH
DPZO-*-25	11,9	12,3	12,4
DPZO-*-27	12,8	13,2	13,3
Option /G		+0,9	

DPZO-A-2














1 = Air bleeding

 $(\mathbf{2})$ = Space to remove the connectors

(3) = The dimensions of all connectors must be considered, see section 16.6 and 16.7

Note: for option /B the solenoid and the on-board digital driver are at side of port B of the main stage




UAB "Domingos prekyba" www.dominga.lt/eshop email: info@dominga.lt


ISO 4401: 2005


Mounting surface: 4401-08-08-0-05 (see table P005)


	Mass [kg]		
	Α	AEB, AES	AES-EH
DPZO-*-45	17,1	18	18,1
DPZO-*-47	18	18,9	19
Option /G		+0,9	


DPZO-A-4











Dotted line = double solenoid version

- 3 (1) = Air bleeding
- $(\mathbf{2})$ = Space to remove the connectors

(3) = The dimensions of all connectors must be considered, see section 16.6 and 16.7


Note: for option /B the solenoid and the on-board digital driver are at side of port B of the main stage




 DOMINGA INDUSTRY SERVICE
 UAB "Domingos prekyba" www.dominga.lt/eshop email: info@dominga.lt

 Savanorių pr. 187- 4 korp., LT-02300 Vilnius, Lietuva, tel.: +370 5 2322231, faks. + 370 5 2648229
UAB "Domingos prekyba" www.dominga.lt/eshop email: info@dominga.lt


option /G








Mounting surface: 4401-10-09-0-05 (see table P005)


	Mass [kg]		
	Α	AEB, AES	AES-EH
DPZO-*-65	42,1	42,5	42,6
DPZO-*-67	42,7	43,1	43,2
Option /G		+2,3	














(3) = The dimensions of all connectors must be considered, see section 16.6 and 16.7

Note: for option /B the solenoid and the on-board digital driver are at side of port B of the main stage



UAB "Domingos prekyba" www.dominga.lt/eshop email: info@dominga.lt

24 RELATED DOCUMENTATION

FS001	Basics for digital electrohydraulics	GS510	Fieldbus
FS900	Operating and maintenance information for proportional valves	K800	Electric and electronic connectors
G010	E-MI-AC analog driver	P005	Mounting surfaces for electrohydraulic valves
G020	E-MI-AS-IR digital driver	QB120	Quickstart for AEB valves commissioning
G030	E-BM-AS digital driver	QF120	Quickstart for AES valves commissioning
GS050	E-BM-AES digital driver		
GS500	Programming tools		



 DOMINGA INDUSTRY SERVICE
 UAB "Domingos prekyba" www.dominga.lt/eshop email: info@dominga.lt

 Savanorių pr. 187- 4 korp., LT-02300 Vilnius, Lietuva, tel.: +370 5 2322231, faks. + 370 5 2648229
UAB "Domingos prekyba" www.dominga.lt/eshop email: info@dominga.lt